



**INSTALLATION** Installation of Crafcoc HFS is summarized as follows. The 2 components of the HFS binder are mixed, and then uniformly applied at the correct rate to the cleaned and prepared pavement surface. Immediately following binder application, the surfacing aggregate is uniformly applied to cover the binder. The HFS Binder is then allowed to cure. Following curing, excess aggregate is removed from the surface. The pavement can then be opened to traffic. For more details on project selection, preparation, installation procedures and clean up, please refer to the Crafcoc Installation Instructions for HFS.

---

**WARRANTY AND DISCLAIMER** Crafcoc Inc. gives no warranty, express or implied, and all products are sold upon condition that purchasers will make their own tests to determine the quality and suitability of the product. Crafcoc Inc. shall be in no way responsible for the proper use and service of the product. The information given in this publication is considered to be accurate and reliable and is provided as a service only. Physical properties shown are typical. Actual properties are dependent on curing conditions and degree of cure. Any information or suggestions given are without warranty of any kind and purchasers are solely responsible for any loss arising from the use of such information or suggestions. No information or suggestions given by us shall be deemed to be a recommendation to use any product in conflict with any existing patent rights.