



420 N. Roosevelt Ave. • Chandler AZ 85226  
1-800-528-8242 • (602) 276-0406 • FAX (480) 961-0513  
www.crafcO.com

ENGINEERING BULLETIN

## BAX 250 & 600 Shut Down Procedures

MARCH 21, 2002

---

We are changing the shutdown procedure for the BAX Applicators. Please notify all customers of the following changes to “SHUTDOWN AND CLEAN-OUT PROCEDURE” on page 13 of the parts manual.

1. Run material level below the top of agitator paddle or as close to empty as possible.
2. Remove bottom reed switch and extend cylinder by activating the pump. Turn hose toggle switch to the “OFF” position.
3. Turn the mixer toggle switch to the “OFF” position.
4. Turn burner toggle switch to the “OFF” position.
5. Store the hose in the hose hanger. **IMPORTANT!! DO NOT** kink or twist hose, as permanent damage will result.
6. Turn the engine “OFF” at the engine key switch.
7. Turn LPG “OFF” at ball valve and valve at LPG bottle.